

2013-08



Processes




Multiprocess Welding

Description



MPi 180 CE



OWNER'S MANUAL





Visit our website at www.MillerWelds.com

File: Multiprocess

From Miller to You

Thank you and *congratulations* on choosing Miller. Now you can get the job done and get it done right. We know you don't have time to do it any other way.

That's why when Niels Miller first started building arc welders in 1929, he made sure his products offered long-lasting value and superior quality. Like you, his customers couldn't afford anything less. Miller products had to be more than the best they could be. They had to be the best you could buy.

Today, the people that build and sell Miller products continue the tradition. They're just as committed to providing equipment and service that meets the high standards of quality and value established in 1929.

This Owner's Manual is designed to help you get the most out of your Miller products. Please take time to read the Safety precautions. They will help you protect yourself against potential hazards on the worksite. We've made installation and operation quick and easy. With Miller you can count on years of reliable service with proper maintenance. And if for some reason the unit needs repair, there's a Troubleshooting section that will help you figure out what the problem is. The parts list will then help you to decide which exact part you may need to fix the problem. Warranty and service information for your particular model are also provided.



Working as hard as you do – every power source from Miller is backed by the most hassle-free warranty in the business.



Miller Electric manufactures a full line of welders and welding related equipment. For

information on other quality Miller products, contact your local Miller distributor to receive the latest full line catalog or individual catalog sheets.



TABLE OF CONTENTS

SECTIO	N 1 – SAFETY PRECAUTIONS - READ BEFORE USING	1
1-1.	Symbol Usage	1
1-2.	Arc Welding Hazards	1
1-3.	Additional Symbols For Installation, Operation, And Maintenance	3
1-4.	California Proposition 65 Warnings	4
1-5.	Principal Safety Standards	4
1-6.	EMF Information	4
SECTIO	N 2 – DEFINITIONS	5
2-1.	Additional Safety Symbols And Definitions	5
2-2.	Miscellaneous Symbols And Definitions	7
SECTIO	N 3 – SPECIFICATIONS	8
3-1.	Serial Number And Rating Label Location	8
3-2.	Specifications	8
3-3.	Duty Cycle And Overheating	8
3-4.	Volt-Ampere Curves	9
3-5.	Environmental Specifications	10
SECTIO	N 4 – INSTALLATION	11
4-1.	Selecting A Location	11
4-2.	Installing Gas Supply	12
4-3.	Weld Output Terminals And Selecting Cable Sizes*	13
4-4.	Process/Polarity Table	13
4-5.	Changing Polarity	14
4-6.	Installing Wire Spool And Adjusting Hub Tension	15
4-7.	Changing Drive Rolls And Wire Inlet Guide	16
4-8.	Aligning Drive Rolls and Wire Guide	17
4-9.	Electrical Service Guide	17
4-10.	Connecting 1-Phase 230 VAC Input Power	18
4-11.	Threading Welding Wire And Adjusting Pressure Roll Tension	20
SECTIO	N 5 – OPERATION	21
5-1.	Controls	21
5-2.	Preparing Unit For Stick Welding	22
5-3.	Preparing Unit For TIG Welding	23
5-4.	Preparing Unit For Manual MIG (GMAW And FCAW) Welding Process	24
5-5.	Slope Time And Burnback Settings	25
5-6.	Fuse F1	25
5-7.	Preparing Unit For Synergic MIG (GMAW And FCAW) Welding Process	26
5-8.	Welding Wire Loading Settings	27
5-9.	Shielding Gas Guide	27
SECTIO	N 6 – MAINTENANCE & TROUBLESHOOTING	28
6-1.	Routine Maintenance	28
6-2.	Welding Gun And Wire Drive Assembly	28
6-3.	Unit Overload	28
6-4.	Troubleshooting	29
SECTIO	N 7 – ELECTRICAL DIAGRAMS	32

TABLE OF CONTENTS

SECTIO	N 8 – MIG WELDING (GMAW) GUIDELINES	34
8-1.	Typical MIG Process Connections	34
8-2.	Typical MIG Process Control Settings	35
8-3.	Holding And Positioning Welding Gun	36
8-4.	Conditions That Affect Weld Bead Shape	37
8-5.	Gun Movement During Welding	38
8-6.	Poor Weld Bead Characteristics	38
8-7.	Good Weld Bead Characteristics	38
8-8.	Troubleshooting – Excessive Spatter	39
8-9.	Troubleshooting – Porosity	39
8-10.	Troubleshooting – Excessive Penetration	39
8-11.	Troubleshooting – Lack Of Penetration	40
8-12.	Troubleshooting – Incomplete Fusion	40
8-13.	Troubleshooting – Burn-Through	40
8-14.	Troubleshooting – Waviness Of Bead	41
8-15.	Troubleshooting – Distortion	41
	Common MIG Shielding Gases	42
8-17.	Troubleshooting Guide For Semiautomatic Welding Equipment	42
SECTIO	N 9 – STICK WELDING (SMAW) GUIDELINES	44
	N 10 – SELECTING AND PREPARING A TEN FOR DC OR AC WELDING	
	VERTER MACHINES	51
10-1.	Selecting Tungsten Electrode (Wear Clean Gloves To Prevent Contamination Of Tungsten)	51
10-2.	Preparing Tungsten Electrode For DC Electrode Negative (DCEN) Welding Or AC Welding With Inverter Machines	51
SECTIO	N 11 – GUIDELINES FOR TIG WELDING (GTAW)	52
	Positioning The Torch	52
11-2.	Torch Movement During Welding	53
11-3.	Positioning Torch Tungsten For Various Weld Joints	53
SECTIO	N 12 - PARTS LIST	54
WARRA	NTY	

DECLARATION OF CONFORMITY



for European Community (CE marked) products.

ITW Welding Products Italy S.r.I Via Privata Iseo 6/E, 20098 San Giuliano M.se, (MI) Italy declares that the product(s) identified in this declaration conform to the essential requirements and provisions of the stated Council Directive(s) and Standard(s).

Product/Apparatus Identification:

Product	Stock Number
MPi 180 230VAC	059016009

Council Directives:

·2006/95/EC Low Voltage

·2004/108/EC Electromagnetic Compatibility

·2011/65/EU Restriction of the use of certain hazardous substances in electrical and electronic equipment

Standards:

·IEC 60974-1 Arc Welding Equipment - Welding Power Sources: edition 3, 2005-07.

·IEC 60974-5 Arc Welding Equipment – Wire Feeders: edition 2, 2007-11.

·IEC 60974-10 Arc Welding Equipment - Electromagnetic Compatibility Requirements: edition 2.0, 2007-08.

•EN 50445:2008 Product family standard to demonstrate compliance of equipment for resistance welding, arc welding and allied processes with the basic restrictions related to human exposure to electromagnetic fields (0Hz-300Hz)

EU Signatory:

Mariho hi-

May 15th , 2013

Massimigliano Lavarini

Date of Declaration

ELECTRONIC ENGINEER R&D TECH. SUPPORT

956 172 109

SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING

som 2011-10

A Protect yourself and others from injury — read, follow, and save these important safety precautions and operating instructions.

1-1. Symbol Usage



DANGER! – Indicates a hazardous situation which, if not avoided, will result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.

NOTICE - Indicates statements not related to personal injury.

1-2. Arc Welding Hazards

The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-5. Read and follow all Safety Standards.

A Only qualified persons should install, operate, maintain, and repair this unit.

During operation, keep everybody, especially children, away.



ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Additional safety precautions are required when any of the following electrically hazardous conditions are present: in damp locations or while wearing wet clothing; on metal structures such as floors, gratings, or scaffolds; when in cramped positions such as sitting, kneeling, or lying; or when there is a high risk of unavoidable or accidental contact with the workpiece or ground. For these conditions, use the following equipment in order presented: 1) a semiautomatic DC constant voltage (wire) welder, 2) a DC manual (stick) welder, or 3) an AC welder with reduced open-circuit voltage. In most situations, use of a DC, constant voltage wire welder is recommended. And, do not work alone!
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install, ground, and operate this equipment according to its Owner's Manual and national, state, and local codes.

[] Indicates special instructions.



This group of symbols means Warning! Watch Out! ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid the hazards.

- Always verify the supply ground check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first double-check connections.
- Keep cords dry, free of oil and grease, and protected from hot metal and sparks.
- Frequently inspect input power cord for damage or bare wiring replace cord immediately if damaged – bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or poorly spliced cables.
- Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Do not touch electrode holders connected to two welding machines at the same time since double open-circuit voltage will be present.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal. Disconnect cable for process not in use.

SIGNIFICANT DC VOLTAGE exists in inverter welding power sources AFTER removal of input power.

• Turn Off inverter, disconnect input power, and discharge input capacitors according to instructions in Maintenance Section before touching any parts.

HOT PARTS can burn.

- Do not touch hot parts bare handed.
- Allow cooling period before working on equipment.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.



FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- If inside, ventilate the area and/or use local forced ventilation at the arc to remove welding fumes and gases.
- If ventilation is poor, wear an approved air-supplied respirator.
- Read and understand the Material Safety Data Sheets (MSDSs) and the manufacturer's instructions for metals, consumables, coatings, cleaners, and degreasers.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watchperson nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.

- Wear an approved welding helmet fitted with a proper shade of filter lenses to protect your face and eyes from arc rays and sparks when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash, glare and sparks; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (leather, heavy cotton, or wool) and foot protection.



WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and

burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Do not weld where flying sparks can strike flammable material.
- Protect yourself and others from flying sparks and hot metal.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
- Do not weld on containers that have held combustibles, or on closed containers such as tanks, drums, or pipes unless they are properly prepared according to AWS F4.1 and AWS A6.0 (see Safety Standards).
- Do not weld where the atmosphere may contain flammable dust, gas, or liquid vapors (such as gasoline).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock, sparks, and fire hazards.
- Do not use welder to thaw frozen pipes.

OM-264 152 Page 2

- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.
- After completion of work, inspect area to ensure it is free of sparks, glowing embers, and flames.
- Use only correct fuses or circuit breakers. Do not oversize or bypass them.
- Follow requirements in OSHA 1910.252 (a) (2) (iv) and NFPA 51B for hot work and have a fire watcher and extinguisher nearby.



FLYING METAL or DIRT can injure eyes.

- Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.
- Wear approved safety glasses with side shields even under your welding helmet.



BUILDUP OF GAS can injure or kill.

- Shut off compressed gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



ELECTRIC AND MAGNETIC FIELDS (EMF) can affect Implanted Medical Devices.

- Wearers of Pacemakers and other Implanted Medical Devices should keep away.
- Implanted Medical Device wearers should consult their doctor and the device manufacturer before going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations.



NOISE can damage hearing.

Noise from some processes or equipment can damage hearing.

• Wear approved ear protection if noise level is high.



CYLINDERS can explode if damaged.

Compressed gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.
- Never weld on a pressurized cylinder explosion will result.
- Use only correct compressed gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Use the right equipment, correct procedures, and sufficient number of persons to lift and move cylinders.
- Read and follow instructions on compressed gas cylinders, associated equipment, and Compressed Gas Association (CGA) publication P-1 listed in Safety Standards.



FIRE OR EXPLOSION hazard.

- Do not install or place unit on, over, or near combustible surfaces.
- Do not install unit near flammables.
- Do not overload building wiring be sure power supply system is properly sized, rated, and protected to handle this unit.



FALLING EQUIPMENT can injure.

- Use lifting eye to lift unit only, NOT running gear, gas cylinders, or any other accessories.
- Use equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to ٠ extend beyond opposite side of unit.
- Keep equipment (cables and cords) away from moving vehicles • when working from an aerial location.
- Follow the guidelines in the Applications Manual for the Revised NIOSH Lifting Equation (Publication No. 94-110) when manually lifting heavy parts or equipment.



OVERUSE can cause OVERHEATING

- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.



FLYING SPARKS can injure.

- Wear a face shield to protect eyes and face.
- Shape tungsten electrode only on grinder with proper guards in a safe location wearing proper face, hand, and body protection.
- Sparks can cause fires keep flammables away.



STATIC (ESD) can damage PC boards.

- Put on grounded wrist strap BEFORE handling • boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.



MOVING PARTS can injure.

- Keep away from moving parts.
- Keep away from pinch points such as drive rolls.



WELDING WIRE can injure.

- Do not press gun trigger until instructed to do SO
- Do not point gun toward any part of the body, • other people, or any metal when threading welding wire.





BATTERY EXPLOSION can injure.

• Do not use welder to charge batteries or jump start vehicles unless it has a battery charging feature designed for this purpose.



MOVING PARTS can injure.

- Keep away from moving parts such as fans.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Have only qualified persons remove doors, panels, covers, or guards for maintenance and troubleshooting as necessary.
- Reinstall doors, panels, covers, or guards when maintenance is finished and before reconnecting input power.



READ INSTRUCTIONS.

- Read and follow all labels and the Owner's • Manual carefully before installing, operating, or servicing unit. Read the safety information at the beginning of the manual and in each section.
- Use only genuine replacement parts from the manufacturer.
- Perform maintenance and service according to the Owner's Manuals, industry standards, and national, state, and local codes.



H.F. RADIATION can cause interference.

- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.



ARC WELDING can cause interference.

- Electromagnetic energy can interfere with sensitive electronic equipment such as computers and computer-driven equipment such as robots.
- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as • possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive electronic equipment.
- Be sure this welding machine is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures • such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.

1-4. California Proposition 65 Warnings

Welding or cutting equipment produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code Section 25249.5 et seq.)

1-5. Principal Safety Standards

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, is available as a free download from the American Welding Society at http://www.aws.org or purchased from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

Safe Practices for the Preparation of Containers and Piping for Welding and Cutting, American Welding Society Standard AWS F4.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

Safe Practices for Welding and Cutting Containers that have Held Combustibles, American Welding Society Standard AWS A6.0, from Global Engineering Documents (phone: 1-877-413-5184,

website: www.global.ihs.com).

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: www.nfpa.org and www. sparky.org).

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 14501 George Carter Way, Suite 103, Chantilly, VA 20151 (phone: 703-788-2700, website:www.cganet.com).

Safety in Welding, Cutting, and Allied Processes, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 5060

1-6. EMF Information

Electric current flowing through any conductor causes localized electric and magnetic fields (EMF). Welding current creates an EMF field around the welding circuit and welding equipment. EMF fields may interfere with some medical implants, e.g. pacemakers. Protective measures for persons wearing medical implants have to be taken. For example, restrict access for passers-by or conduct individual risk assessment for welders. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:

- 1. Keep cables close together by twisting or taping them, or using a cable cover.
- 2. Do not place your body between welding cables. Arrange cables to one side and away from the operator.
- 3. Do not coil or drape cables around your body.

This product contains chemicals, including lead, known to the state of California to cause cancer, birth defects, or other reproductive harm. Wash hands after use.

Spectrum Way, Suite 100, Ontario, Canada L4W 5NS (phone: 800-463-6727, website: www.csa-international.org).

Safe Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute, 25 West 43rd Street, New York, NY 10036 (phone: 212-642-4900, website: www.ansi.org).

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: www.nfpa.org.

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, from U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250-7954 (phone: 1-866-512-1800) (there are 10 OSHA Regional Offices phone for Region 5, Chicago, is 312-353-2220, website: www.osha.gov).

Applications Manual for the Revised NIOSH Lifting Equation, The National Institute for Occupational Safety and Health (NIOSH), 1600 Clifton Rd, Atlanta, GA 30333 (phone: 1-800-232-4636, website: www.cdc.gov/NIOSH).

- 4. Keep head and trunk as far away from the equipment in the welding circuit as possible.
- 5. Connect work clamp to workpiece as close to the weld as possible.
- 6. Do not work next to, sit or lean on the welding power source.
- 7. Do not weld whilst carrying the welding power source or wire feeder.

About Implanted Medical Devices:

Implanted Medical Device wearers should consult their doctor and the device manufacturer before performing or going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations. If cleared by your doctor, then following the above procedures is recommended.

2-1. Additional Safety Symbols And Definitions

□ Some symbols are found only on CE products.

		
	Warning! Watch Out! There are possible hazards as shown by the symbols.	Safe1 2012-05
A A A A A A A A A A A A A A A A A A A	Wear dry insulating gloves. Do not touch electrode with bare hand. Do not wear wet or damaged gloves.	Safe2 2012-05
	Protect yourself from electric shock by insulating yourself from work and ground.	Safe3 2012-05
	Keep your head out of the fumes.	Safe6 2012-05
	Use forced ventilation or local exhaust to remove the fumes.	Safe8 2012-05
	Use ventilating fan to remove fumes.	Safe10 2012-05
	Keep flammables away from welding. Do not weld near flammables.	Safe12 2012-05
	Welding sparks can cause fires. Have a fire extinguisher nearby, and have a watchperson ready to use it	Safe14 2012–05
	Do not weld on drums or any closed containers.	Safe16 2012-05
	Do not remove or paint over (cover) the label.	Safe20 2012-05

Disconnect input plug or power l	before working on machine. Safe5 2012-05					
facility.	eral waste. al and Electronic Equipment (WEEE) by disposing at a designated collection ce or your local distributor for further information. Safe37 2012-05					
Disconnect input plug or power	before working on machine. Safe30 2012-05					
Become trained and read the ins	structions and labels before working on machine. Safe35 2012-05					
? V ? A Consult rating label for input pov	Consult rating label for input power requirements.					
Drive rolls can injure fingers.	Safe32 2012-05					
Welding wire and drive parts are	e at welding voltage during operation – keep hands and metal objects away. Safe33 2012-05					
	Wear hat and safety glasses. Use ear protection and button shirt collar. Use welding helmet with correct shade of filter. Wear complete body protection.					
	Become trained and read the instructions before working on the machine or welding.					
	Move jumper links as shown on inside label to match input voltage at job site. Include extra length in grounding conductor and connect grounding conductor first. Connect line input conductors as shown on inside label. Double-check all connections, jumper link positions, and input voltage before applying power. Safe49 2012-05					

2-2. Miscellaneous Symbols And Definitions

Some symbols are found only on CE products.

Α	Amperes	V	Volts	\sim	Alternating Current (AC)		Direct Current (DC)
	Remote		On	0	Off		Protective Earth (Ground)
	Line Connection		Single Phase Static Frequency Converter- Transformer- Rectifier	1⁄~	Single Phase	15- 15-	Gas Metal Arc Welding (GMAW)
U ₁	Primary Voltage	1max	Rated Maximum Supply Current	1eff	Maximum Effective Supply Current	U ₂	Conventional Load Voltage
I ₂	Rated Welding Current	Χ	Duty Cycle	%	Percent	U _o	Rated No Load Voltage (Average)
IP	Degree Of Protection		Fuse	t	Slope Time	H	Shielded Metal Arc Welding (SMAW)
	Gas Input		Gas Output		Voltage Input	0	Wire Feed
Hz	Hertz	Þ	Input	<u></u>	Gas Tungsten Arc Welding (GTAW)		Read Operator's Manual
. <u>.</u> t. t	Wire Burnback Control		Diameter	\bigcirc	Increase/Decrease		

Notes

3-1. Serial Number And Rating Label Location


The serial number and rating information for this product is located on the bottom. Use rating label to determine input power requirements and/or rated output. For future reference, write serial number in space provided on back cover of this manual.

Operating Temperature Range: -10° C (14° F) to 40° C (104° F). Ratings were developed at an ambient temperature of 20° C to 25° C.

3-2. Specifications

Model	Input Power Single Phase AC 50/60 Hz Voltage		Rated Outpu	t	Max. Open Circuit Voltage	Amperage/Voltage Range DC	Input KVA	Input KW	Dimension (mm)	Weight (Kg)
	230 Volts	100%	60%	20%		20 4 100 4				
	MIG	90 A 18.5 V	115 A 19.8 V	180 A 23.0 V	30 V	30 A - 180 A 15.5 V - 23.0 V				
	000 \ / - !! -	100%	60%	25%					L = 548	
MPi 180	230 Volts TIG	90 A 13.6 V	115 A 14.6 V	175 A 17.0 V	58 V	5 A - 175 A 10.2 V - 17.0 V	7.6	6.0	W = 237 H = 365	15.2 Kg
		100%	60%	20%						
	230 Volts STICK	80 A 23.2 V	100 A 24.0 V	175 A 27.0 V	58 V	5 A - 175 A 20.2 V - 27.0 V				


3-3. Duty Cycle And Overheating




3-4. Volt-Ampere Curves

The volt-ampere curves show the minimum and maximum voltage and amperage output capabilities of the welding power source. Curves of other settings fall between the curves shown.

A. MIG



B. TIG/Stick



3-5. Environmental Specifications

A. IP Rating

IP Rating	Operating Temperature Range
IP22S	
This equipment is designed for indoor use and is not intended to be used or stored outside.	14 to 104°F (–10 to 40°C)

B. Information On Electromagnetic Fields (EMF)

A This equipment shall not be used by the general public as the EMF limits for the general public might be exceeded during welding.

This equipment is built in accordance with EN 60974–1 and is intended to be used only in an occupational environment (where the general public access is prohibited or regulated in such a way as to be similar to occupational use) by an expert or an instructed person.

Wire feeders and ancillary equipment (such as torches, liquid cooling systems and arc striking and stabilizing devices) as part of the welding circuit may not be a major contributor to the EMF. See the Owner's Manuals for all components of the welding circuit for additional EMF exposure information.

- The EMF assessment on this equipment was conducted at 0.5 meter.
- At a distance of 1 meter the EMF exposure values were less than 20% of the permissible values.

ce-emf 1 2010-10

C. Information On Electromagnetic Compatibility (EMC)


This Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low voltage supply system. There can be potential difficulties in ensuring electromagnetic compatibility in those locations, due to conducted as well as radiated disturbances.

This equipment does not comply with IEC 61000–3–12. If it is connected to a public low voltage system, it is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment can be connected.


ce-emc 2 2011-09

Notes

SECTION 4 – INSTALLATION



4-2. Installing Gas Supply



Obtain gas cylinder and chain to running gear, wall, or other stationary support so cylinder cannot fall and break off valve.

I Cap

Cylinder Valve

Remove cap, stand to side of valve, and open valve slightly. Gas flow blows dust and dirt from valve. Close valve.

- 3 Cylinder
- 1 Regulator/Flowmeter

Install so face is vertical.

- Regulator/Flowmeter Gas
 Hose Connection
- 6 Welding Power Source Gas Hose Connection

Connect supplied gas hose between regulator/flowmeter gas hose connection, and fitting on rear of welding power source.

Flow Adjust

Typical flow rate is between 12-15 liters per minute. Check wire manufacturer's recommended flow rate.

- 8 CO₂ Adapter (Customer Supplied)
- 9 O-Ring (Customer Supplied)

Install adapter with O-ring between regulator/flowmeter and CO_2 cylinder.

956172107_1-A


4-3. Weld Output Terminals And Selecting Cable Sizes*

NOTICE – The Total Cable Length in Weld Circuit (see table below) is the combined length of both weld cables. For example, if the power source is 30 m (100 ft) from the workpiece, the total cable length in the weld circuit is 60 m (2 cables x 30 m). Use the 60 m (200 ft) column to determine cable size.


Weld Output Terminals ▲ Turn off power be- fore connecting to weld output termi- nals. ▲ Do not use worn, damaged, under- sized, or poorly			eld Cable Siz		tal Cable (Not Exceed 60 m (200 ft)		ength in W 90 m (300 ft)	'eld Circuit 105 m (350 ft)	120 m (400 ft)
spliced cables.	Welding Amperes	10 - 60% Duty Cycle mm ² (AWG)	60 - 100% Duty Cycle mm ² (AWG)				Duty Cycle (AWG)	3	
	100	20 (4)	20 (4)	20 (4)	30 (3)	35 (2)	50 (1)	60 (1/0)	60 (1/0)
	150	30 (3)	30 (3)	35 (2)	50 (1)	60 (1/0)	70 (2/0)	95 (3/0)	95 (3/0)
<u> </u>	200	30 (3)	35 (2)	50 (1)	60 (1/0)	70 (2/0)	95 (3/0)	120 (4/0)	120 (4/0)
Negative Positive (-) (+)	250	35 (2)	50 (1)	60 (1/0)	70 (2/0)	95 (3/0)	120 (4/0)	2x70 (2x2/0)	2x70 (2x2/0)
Ref. 956172107_6-A									
**Weld cable size is based of						-			
***For distances longer than those shown in this guide, call a factory applications representative. Milan Ref. S-0007-J 2011-07									


4-4. Process/Polarity Table

Process	Polarity	Cable Co	onnections
		Cable To Gun	Cable To Work
GMAW Solid wire with shielding gas	DCEP Reverse polarity	Connect to positive (+) output terminal	Connect to negative (-) output terminal
FCAW Self-shielding wire and no shielding gas	DCEN Straight polarity	Connect to negative (-) output terminal	Connect to positive (+) output terminal




4-5. Changing Polarity





Changing Drive Rolls And Wire Inlet Guide 4-7.

4-8. Aligning Drive Rolls and Wire Guide



4-9. Electrical Service Guide

Elec Serv 2011-08

A Failure to follow these electrical service guide recommendations could create an electric shock or fire hazard. These recommendations are for a dedicated branch circuit sized for the rated output and duty cycle of the welding power source.

	50/60 Hz Single Phase
Input Voltage (V)	230
Input Amperes (A) At Rated Output	33
Max Recommended Standard Fuse Rating In Amperes ¹	
Time-Delay Fuses ²	40
Normal Operating Fuses ³	50
Min Input Conductor Size In AWG ⁴	4 (14)
Max Recommended Input Conductor Length In Meters (Feet)	13 (42)
Min Grounding Conductor Size In mm ² (AWG) ⁴	4 (14)

Reference: 2011 National Electrical Code (NEC) (including article 630)


1 If a circuit breaker is used in place of a fuse, choose a circuit breaker with time-current curves comparable to the recommended fuse.

2 "Time-Delay" fuses are UL class "RK5" . See UL 248.


3 "Normal Operating" (general purpose - no intentional delay) fuses are UL class "K5" (up to and including 60 amps), and UL class "H" (65 amps and above).


4 Conductor data in this section specifies conductor size (excluding flexible cord or cable) between the panelboard and the equipment per NEC Table 310.15(B)(16). If a flexible cord or cable is used, minimum conductor size may increase. See NEC Table 400.5(A) for flexible cord and cable requirements.


4-10. Connecting 1-Phase 230 VAC Input Power



4-10. Connecting 1-Phase 230 VAC Input Power (Continued)








4-11. Threading Welding Wire And Adjusting Pressure Roll Tension

OM-264 152 Page 20

SECTION 5 – OPERATION

5-1. Controls



1 Power Switch S1

Use switch to turn power on and off.

2 Digital Display Meter (Left)

Displays actual output current value during welding, and displays selected parameter from position of Process Selector control while in idle mode.

3 Power Indicator Light (Green LED)

PL1 is lit when power is on.

4 High Temperature Shutdown Light (Yellow LED)

PL2 lights up when unit overheats and shuts down.

5 Over-Current Light

PL3 is lit if an over-current condition is present.

6 Digital Display Meter (Right)

Displays actual arc voltage value during welding, and displays selected parameter from position of Process Selector control while in idle mode.

- 7 Process Selector Control Knob (TIG/Stick/MIG/Synergic MIG Processes)
- Unit will display "Err" (error) on left display and "POS" on right display if Process Selector control knob is located in a position that is not allowed.
- 8 Hot Start (Stick)/Arc Voltage (MIG)/Output Power Percentage (SYN MIG) Control Knob
- 9 Positive Weld Output Receptacle

For Stick welding, connect electrode cable to this receptacle. For TIG welding, connect work cable to this receptacle.

10 Negative Weld Output Receptacle

For Stick and MIG welding, connect work cable to this receptacle. For TIG welding, connect torch cable to this receptacle.


11 MIG Torch Connection

Connection for Euro style MIG gun.

12 Amperage (TIG/Stick)/Wire Feed Speed (MIG/SYN MIG) Control Knob

956172107_6-A

5-2. Preparing Unit For Stick Welding



1 Digital Display Meter (Left) (See Section 5-1)

Displays preset amperage value.

- 2 Process Selector Control Knob (See Section 5-1)
- 3 Digital Display Meter (Right) (See Section 5-1)

Displays hot start value.

4 Hot Start Control Knob (See Section 5-1)

Adjusts hot start value, this is variable from 0 to 50% of the preset amperage value.

IF preset amperage is 110A and control is set to 0, starting amperage is 110A. If control is set to 50% (max.) starting amperage is 165A. If preset amperage is 160A and control is set to 0, starting amperage is 160A. If control is set to 50% (max.) starting amperage would be 240A, but maximum amperage in hot start is set to 230A. In this case, starting amperage would be 230A.

5 Amperage Control Knob (See Section 5-1)

Adjusts amperage value, this is within a range from 5A (min.) to 175A (max.).

Prepare unit for Stick welding as follow-ings:


- Connect selectrode holder to positive weld output receptacle.
- Connect work clamp to negative weld output terminal.
- Turn power on.

- Allow time for unit to complete its startup cycle
- Use the Process Selector Control knob to select STICK process.
- Use the Amperage Control knob to set desired amperage value. Turn knob clockwise to increase amperage (min. – max.).
- Use the Hot Start Contro knob to adjust the arc starting amperage value. Turn knob clockwise to increase (min. – max.).

Hot Start Setting

Use Hot Start to increase output amperage at the start of a weld to help prevent electrode sticking.

5-3. Preparing Unit For TIG Welding



1 Digital Display Meter (Left) (See Section 5-1)

Displays preset amperage value.

- 2 Process Selector Control Knob (See Section 5-1)
- 3 Digital Display Meter (Right) (See Section 5-1)
- In TIG mode this meter is not active.
- 4 Hot Start Control Knob (See Section 5-1)


- In TIG mode this control is not active.
- 5 Amperage Control Knob (See Section 5-1)

Adjusts amperage value, this is within a range from 5A (min.) to 175A (max.).

Prepare unit for TIG welding as follows:

- Connect electrode holder to negative weld output receptacle.
- Connect work clamp to positive weld output terminal.
- Turn power on. Allow time for unit complete its start up cycle.
- Use thr Process Selector control knob to select TIG process.
- Use amperage adjustment control knob to set desired amperage value. Rotate knob clockwise to increase amperage (min - max).

5-4. Preparing Unit For Manual MIG (GMAW And FCAW) Welding Process



1 Digital Display Meter (Left) (See Section 5-1)

Displays wire feed speed value.

- 2 Process Selector Control Knob (See Section 5-1)
- 3 Digital Display Meter (Right) (See Section 5-1)
- Displays the no-load voltage value.
- 4 Arc Voltage Control Knob (See Section 5-1)
- Adjusts no-load voltage value.
- 5 Wire Feed Speed (WFS) Control Knob (See Section 5-1)
- Adjusts wire feed speed value.

To select MIG welding proceed as follows:

- Prepare unit according to Section 4.
- Use a cable with correct adapter, connect gun to the MIG gun connector.
- For GMAW process:
- Connect wire drive lead to positive output terminal. Connect work clamp lead to negative output terminal. See Section 4-4 for GMAW solid wire with shielding gas process. See Section 4-2 for installing gas supply.
- For FCAW process:

Connect wire drive lead to negative output terminal. Connect work clamp lead to positive output terminal. See Section 4-4 for FCAW self-shielding wire no shielding gas process.


 Use Process Selector control knob to select MIG process.

• Use Arc Voltage control knob to select desired welding voltage. Rotate clockwise to increase output voltage value (min. = 13 volts DC, max. = 30 volts DC).

• Use Wire Feed Speed (WFS) control knob to select desired wire feed speed. Rotate knob clockwise to increase WFS value (min. = 1.5 mpm, max. = 21.6 mpm).

Solution Without the encoder, wire feed speed values may have small changes.

5-5. Slope Time And Burnback Settings



1 Slope Time Control Knob


Use control knob to select amount of time that it takes to slope up/ down from initial amperage to weld amperage. Turn knob clockwise to increase value (min. 0 to max. 1.5 sec).

2 Burnback Time (BBT)


Use control knob to set time that welding wire stays energized after trigger is released. Turn knob clockwise to increase value (min. 0 to max. 400 ms).

956172107_12-B

5-6. Fuse F1



5-7. Preparing Unit For Synergic MIG (GMAW And FCAW) Welding Process



1 Digital Display Meter (Left) (See Section 5-1)

Displays a percentage of adjustment to the preset wire feed speed value.

- 2 Process Selector Control Knob (See Section 5-1)
- 3 Digital Display Meter (Right) (See Section 5-1)

Displays a percentage of the adjustment to the preset amperage value.

4 Amperage Control Knob (See Section 5-1)

Adjusts a percentage to the adjustment of the selected amperage in the synergic curve. The range is from 1% min. to 100% max. of the preset amperage, depending on workpiece thickness. Turn knob clockwise to increase the value.

5 Wire Feed Speed (WFS) Control Knob (See Section 5-1)

Adjusts a percentage of the adjustment to the preset wire feed speed value. "0" value displayed on left display means no change to preset WFS value. Turn knob clockwise to increase WFS within a range of 0% to 40% of preset value. Turn knov counterclockwise to decrease WFS within a range of 0% to 40% of preset WFS value.

IF Wire feed speed depends on the output voltage, up to a maximum WFS of 22 mpm.


To select synergic MIG welding process, proceed as follows:

- Prepare unit according to Section 4.
- Use a cable with correct adapter, connect gun to the MIG gun connector.
- · For GMAW process:
- Connect wire drive lead to positive output terminal. Connect work lead to negative output terminal. See Section 4-4 for GMAW solid wire with shielding gas process. See Section 4-2 for installing gas supply.
- · For FCAW process:
- Connect wire drive lead to negative output terminal. Connect work clamp lead to positive output terminal. See

956172107_16-A

- Section 4-4 for FCAW self-shielding wire no shielding gas process.
- Use Process Selector control knob to select desired synergic MIG process.
- Use Amperage control knob to select desired amperage. Rotate knob clockwise to increase the value.
- The minimum and maximum weldable thicknesses and the relationship to the corresponding welding parameters (amperage/voltage) depend on the selected synergic curve.
- Use WFS control knob to select desired wire feed speed. Rotate knob clockwise to increase WFS percentage value.
- In Synergic MIG mode, the operator may need to adjust welding data (wire type, wire diameter and gas type) and only one weld parameter. Generally, wire feed speed is adjusted and the synergic process automatically sets appropriate weld voltage. Synergic welding also sets many secondary welding parameters automatically for improved weld quality.

5-8. Welding Wire Loading Settings



Prepare unit for welding wire loading as follows:

- Install wire spool and adjust hub tension (see Section 4-6).
- Use proper drive rolls and wire guide (see Section 4-7).
- Thread welding wire and adjust pressure roll tension (see Section 4-11).

Without starting a weld, press and hold torch trigger for three seconds to load welding wire.

After pressing and holding the torch trigger, gas valve is disabled. Welding wire will be loaded at a wire feed value of about 8.5 mpm. The wire feed speed is only measured in meters per minute.

To stop loading wire, release torch trigger.

956172107_7-A

5-9. Shielding Gas Guide


Material	Gas Type	Note
Mild Steel	Argon + CO ₂ + Oxygen	Oxygen inproves arc stability
Aluminum	Argon + Helium	Higher heat input suitable for heavy sections
Stainless Steel	Argon + CO ₂ + Oxygen	Arc stability
Stall liess Steel	Argon + Oxygen	Minimum spatter
Copper, Nickel, and Alloys	Argon + Helium	Higher heat input suitable for heavy sections

SECTION 6 – MAINTENANCE & TROUBLESHOOTING

6-1. Routine Maintenance

				Maintain more often during severe conditions.
		Change 🕥 = Clean Authorized Service Agent	☆ = Replace	Reference
Every 3 Months			× / ×	
	\star Unreadable Labels	Weld Terminals	✓☆ Weld Cables	
Every 6 Months	A COR OR	0-0-		
	Inside Unit	✓ Apply Light Coat Of Oil Or Grease To Drive Motor Shaft	Clean Drive Rolls	

6-2. Welding Gun And Wire Drive Assembly



6-3. Unit Overload

Thermal switch TP1 located on the primary heatsink protects the unit from damage due to overheating. If TP1 has opened due to overheating, wait for unit to cool allowing fan motor to run before trying to weld. If unit is cool and no weld output continues, contact Factory Authorized Service Agent.

OM-264 152 Page 28

6-4. Troubleshooting



A. MIG (GMAW) Welding

Trouble	Remedy	
No weld output; wire does not feed.	Be sure line disconnect switch is On (see Section 4-10).	
	Replace building line fuse or reset circuit breaker if open (see Section 4-10).	
	Secure gun trigger connections (see welding gun Owner's Manual).	
	Check continuity of power switch S1 and replace if necessary.	
	Have Factory Authorized Service Agent check main transformer T1 for signs of winding failure. Check continuity across windings and check for proper connections. Check secondary voltages. Replace T1 if necessary.	
	Have Factory Authorized Service Agent check continuity of thermostat TP1. Replace TP1 if necessary.	
	Have Factory Authorized Service Agent check main control board PC2 and connections, and replace if necessary.	
	Have Factory Authorized Service Agent check all board connections and main control board.	
No weld output; wire feeds.	Connect work clamp to get good metal to metal contact.	
	Replace contact tip (see welding gun Owner's Manual).	
	An overload condition occurred (see Section 6-3).	
	Have Factory Authorized Service Agent check primary and secondary power circuit of the unit.	
	Have Factory Authorized Service Agent check main transformer T1 for signs of winding failure. Check continuity across windings and check for proper connections. Check secondary voltages. Replace T1 if necessary.	
	Have Factory Authorized Service Agent check voltage switch(es), and replace if necessary.	
Low weld output.	Connect unit to proper input voltage or check for low line voltage (see Section 4-10).	
Low, high, or erratic wire speed.	Readjust front panel settings (see Section 5).	
	Change to correct size drive rolls (see Section 4-7).	
	Readjust drive roll pressure (see Section 4-11).	
	Replace inlet guide, contact tip, and/or liner if necessary (see welding gun Owner's Manual).	
	Have Factory Authorized Service Agent check Wire Speed control, and replace if necessary.	
	Have Factory Authorized Service Agent check motor control board PC4 and connections, and replace if necessary.	
No wire feed.	Rotate Wire Speed control to higher setting (see Section 5).	
	Clear obstruction in gun contact tip or liner (see welding gun Owner's Manual).	
	Readjust drive roll pressure (see Section 4-11).	
	Change to correct size drive rolls (see Section 4-7).	
	Rethread welding wire (see Section 4-11).	
	Check gun trigger and leads. Repair or replace gun if necessary.	
	Have Factory Authorized Service Agent check main control board.	

B. Stick (SMAW) Welding


Trouble	Remedy
Hard starts, poor welding characterist- ics, unusual spattering.	Use proper type and size of electrode.
	Check electrode polarity and reverse in necessary; check and correct poor connections
	Make sure a remote control is not connected.

C. TIG (GTAW) Welding


Trouble	Remedy
Wandering arc, hard starts, poor welding characteristics, spattering problems.	Use proper type and size of tungsten.
	Use properly prepared tungsten.
	Check electrode polarity and reverse if necessary.
Tungsten electrode oxidizing and not remaining bright after welding.	Shield weld zone from drafts.
remaining bright alter weiding.	Check for correct type shielding gas.
	Check and tighten gas fittings.
	Check electrode polarity and reverse if necessary.

Notes











956172108-B

SECTION 8 – MIG WELDING (GMAW) GUIDELINES




8-2. Typical MIG Process Control Settings

These settings are guidelines only. Material and wire type, joint design, fitup, position, shielding gas, etc. affect settings. Test welds to be sure they comply to specifications.




8-3. Holding And Positioning Welding Gun

Solution wire is energized when gun trigger is pressed. Before lowering helmet and pressing trigger, be sure wire is no more than 1/2 in. (13 mm) past end of nozzle, and tip of wire is positioned correctly on seam.




8-4. Conditions That Affect Weld Bead Shape

Solution with the set of the set




8-5. Gun Movement During Welding


Sormally, a single stringer bead is satisfactory for most narrow groove weld joints; however, for wide groove weld joints or bridging across gaps, a weave bead or multiple stringer beads works better.



8-6. Poor Weld Bead Characteristics



8-7. Good Weld Bead Characteristics



8-8. Troubleshooting – Excessive Spatter


<u></u>

Excessive Spatter – scattering of molten metal particles that cool to solid form near weld bead.

S-0636

Possible Causes	Corrective Actions	
Wire feed speed too high.	Select lower wire feed speed.	
Voltage too high.	Select lower voltage range.	
Electrode extension (stickout) too long.	Use shorter electrode extension (stickout).	
Workpiece dirty.	Remove all grease, oil, moisture, rust, paint, undercoating, and dirt from work surface before welding.	
Insufficient shielding gas at welding arc.	Increase flow of shielding gas at regulator/flowmeter and/or prevent drafts near welding arc.	
Dirty welding wire.	Use clean, dry welding wire.	
	Eliminate pickup of oil or lubricant on welding wire from feeder or liner.	
Incorrect polarity.	Check polarity required by welding wire, and change to correct polarity at welding power source.	

8-9. Troubleshooting – Porosity



 $\ensuremath{\mathsf{Porosity}}$ – small cavities or holes resulting from gas pockets in weld metal.

S-0635

Possible Causes	Corrective Actions		
Insufficient shielding gas at welding arc.	Increase flow of shielding gas at regulator/flowmeter and/or prevent drafts near welding arc.		
	Remove spatter from gun nozzle.		
	Check gas hoses for leaks.		
	Place nozzle 1/4 to 1/2 in. (6-13 mm) from workpiece.		
	Hold gun near bead at end of weld until molten metal solidifies.		
Wrong gas.	Use welding grade shielding gas; change to different gas.		
Dirty welding wire.	Use clean, dry welding wire.		
	Eliminate pick up of oil or lubricant on welding wire from feeder or liner.		
Workpiece dirty.	Remove all grease, oil, moisture, rust, paint, coatings, and dirt from work surface before welding.		
	Use a more highly deoxidizing welding wire (contact supplier).		
Welding wire extends too far out of nozzle.	e. Be sure welding wire extends not more than 1/2 in. (13 mm) beyond nozzle.		

8-10. Troubleshooting – Excessive Penetration

Excessive Penetration Good Penetra	Excessive Penetration – weld metal melting through base metal and hanging underneath weld.
Possible Causes	Corrective Actions

Possible Causes	Corrective Actions	
Excessive heat input.	Select lower voltage range and reduce wire feed speed.	
	Increase travel speed.	

S-0639

8-11. Troubleshooting – Lack Of Penetration



ook of Dor Good Dopotration Lack Of Penetration - shallow fusion between weld metal and base metal.

Lack of Penetration Good Penetration S-0638		
Possible Causes	Corrective Actions	
Improper joint preparation.	Material too thick. Joint preparation and design must provide access to bottom of groove while maintaining proper welding wire extension and arc characteristics.	
Improper weld technique.	Maintain normal gun angle of 0 to 15 degrees to achieve maximum penetration.	
	Keep arc on leading edge of weld puddle.	
	Be sure welding wire extends not more than 1/2 in. (13 mm) beyond nozzle.	
Insufficient heat input.	Select higher wire feed speed and/or select higher voltage range.	
	Reduce travel speed.	
Incorrect polarity.	Check polarity required by welding wire, and change to correct polarity at welding power source.	


8-12. Troubleshooting – Incomplete Fusion

	Incomplete Fusion – failure of weld metal to fuse completely with base metal or a preceeding weld bead.		
Possible Causes	Corrective Actions		
Workpiece dirty.	Remove all grease, oil, moisture, rust, paint, undercoating, and dirt from work surface before welding.		
Insufficient heat input.	Select higher voltage range and/or adjust wire feed speed.		
Improper welding technique.	Place stringer bead in proper location(s) at joint during welding.		
Adjust work angle or widen groove to access bottom during welding.Momentarily hold arc on groove side walls when using weaving technique.			
			Keep arc on leading edge of weld puddle.
	Use correct gun angle of 0 to 15 degrees.		

8-13. Troubleshooting – Burn-Through

	Burn-Through – weld metal melting completely through base metal resulting in holes where no metal remains.)
Possible Causes	Corrective Actions	-
Excessive heat input.	Select lower voltage range and reduce wire feed speed.	
	Increase and/or maintain steady travel speed.	

8-14. Troubleshooting – Waviness Of Bead



8-15. Troubleshooting – Distortion

in the d	Distortion – contraction of weld metal during welding that forces base metal to move. lirection of eld bead. S-0642	
Possible Causes	Corrective Actions	
Excessive heat input.	Use restraint (clamp) to hold base metal in position.	
	Make tack welds along joint before starting welding operation.	
Select lower voltage range and/or reduce wire feed speed. Increase travel speed.		
		Weld in small segments and allow cooling between welds.

8-16. Common MIG Shielding Gases

This is a general chart for common gases and where they are used. Many different combinations (mixtures) of shielding gases have been developed over the years. The most commonly used shielding gases are listed in the following table.

	Application			
Gas	Spray Arc Steel	Short Circuiting Steel	Short Circuiting Stainless Steel	Aluminum
Argon				Х
Argon + 25% CO ₂		X		
80% or greater Argon + balance CO ₂ or Oxygen	Х	X1		
100% CO ₂		X		
Tri-Mix ²			X	

1 Limited short circuiting use

2 90% HE + 7-1/2% AR + 2-1/2% CO₂

8-17. Troubleshooting Guide For Semiautomatic Welding Equipment

Problem	Probable Cause	Remedy	
Wire feed motor operates, but wire does not feed.	Too little pressure on wire feed rolls.	Increase pressure setting on wire feed rolls.	
	Incorrect wire feed rolls.	Check size stamped on wire feed rolls, replace to match wire size and type if necessary.	
	Wire spool brake pressure too high.	Decrease brake pressure on wire spool.	
	Restriction in the gun and/or assembly.	Check and replace cable, gun, and contact tip if damaged. Check size of contact tip and cable liner, replace if necessary.	
Wire curling up in front of the wire feed rolls (bird nesting).	Too much pressure on wire feed rolls.	Decrease pressure setting on wire feed rolls.	
wire leeu loiis (biru hestilig).	Incorrect cable liner or gun contact tip size.	Check size of contact tip and check cable liner length and diameter, replace if necessary.	
	Gun end not inserted into drive housing properly.	Loosen gun securing bolt in drive housing and push gun end into housing just enough so it does not touch wire feed rolls.	
	Dirty or damaged (kinked) liner.	Replace liner.	
Wire feeds, but no gas flows.	Gas cylinder empty.	Replace empty gas cylinder.	
	Gas nozzle plugged.	Clean or replace gas nozzle.	
	Gas cylinder valve not open or flowmeter not adjusted.	Open gas valve at cylinder and adjust flow rate.	
	Restriction in gas line.	Check gas hose between flowmeter and wire feeder, and gas hose in gun and cable assembly.	
	Loose or broken wires to gas solenoid.	Have Factory Authorized Service Agent repair wiring.	
	Gas solenoid valve not operating.	Have Factory Authorized Service Agent replace gas solenoid valve.	
	Incorrect primary voltage connected to welding power source.	Check primary voltage and relink welding power source for correct voltage.	
Welding arc not stable.	Wire slipping in drive rolls.	Adjust pressure setting on wire feed rolls. Replace worn drive rolls if necessary.	
	Wrong size gun liner or contact tip.	Match liner and contact tip to wire size and type.	

Problem	Probable Cause	Remedy
	Incorrect voltage setting for selected wire feed speed on welding power source.	Readjust welding parameters.
	Loose connections at the gun weld cable or work cable.	Check and tighten all connections.
Gun in poor shape or loose connection inside gun.		Repair or replace gun as necessary.

SECTION 9 - STICK WELDING (SMAW) GUIDELINES


Weld current starts when electrode touches workpiece. Equipment Needed: Tools Needed: A Weld current can damage CONTRACTOR electronic parts in vehicles. Disconnect both battery 6 cables before welding on a vehicle. Place work clamp as close to the weld as possible. IF Always wear appropriate personal protective clothing. 1 Workpiece Make sure workpiece is clean be-**Constant Current** fore welding. Welding Power Source 2 Work Clamp 3 Electrode A small diameter electrode requires less current than a large one. Follow electrode manufacturer's instructions when setting weld amperage (see Section 9-2). 4 Insulated Electrode Holder Electrode Holder Position 5 6 Arc Length Arc length is the distance from the electrode to the workpiece. A short arc with correct amperage will give a sharp, crackling sound. 7 Slag Use a chipping hammer and wire brush to remove slag. Remove slag and check weld bead before making another weld pass. 1 7

9-1. Stick Welding Procedure

stick 2010-02 - 151 593

9-2. Electrode and Amperage Selection Chart






ELECTRODE	*OQ	AC	NOILISOd	PENETRATION	USAGE	
6010	EP		ALL	DEEP	MIN. PREP, ROUGH	
6011	EP	/	ALL	DEEP	HIGH SPATTER	
6013	EP,EN	/	ALL	LOW	GENERAL	
7014	EP,EN	1	ALL	MED	SMOOTH, EASY, FAST	
7018	EP	1	ALL	MED	LOW HYDROGEN STRONG	
7024	EP,EN	1	FLAT HORIZ FILLET	LOW	SMOOTH, EASY, FASTER	
NI-CL	EP	/	ALL	LOW	CAST IRON	
308L	EP	/	ALL	LOW	STAINLESS	
*EP = EN =	*EP = ELECTRODE POSITIVE (REVERSE POLARITY) EN = ELECTRODE NEGATIVE (STRAIGHT POLARITY)					

Ref. S-087 985-A

9-3. Striking an Arc



- 1 Electrode
- 2 Workpiece
- 3 Arc


Scratch Technique

Drag electrode across workpiece like striking a match; lift electrode slightly after touching work. If arc goes out, electrode was lifted too high. If electrode sticks to workpiece, use a quick twist to free it.


Tapping Technique

Bring electrode straight down to workpiece; then lift slightly to start arc. If arc goes out, electrode was lifted too high. If electrode sticks to workpiece, use a quick twist to free it.


S-0049 / S-0050




9-5. Poor Weld Bead Characteristics




9-6. Good Weld Bead Characteristics









9-8. Electrode Movement During Welding





9-12. Weld Test



9-13. Troubleshooting

	Porosity – small cavities or holes resulting from gas pockets in weld metal.
Possible Causes	Corrective Actions
Arc length too long.	Reduce arc length.
Damp electrode.	Use dry electrode.
Workpiece dirty.	Remove all grease, oil, moisture, rust, paint, coatings, slag, and dirt from work surface before welding.
	Excessive Spatter – scattering of molten metal particles that cool to solid form near weld bead.
Possible Causes	Corrective Actions
Amperage too high for electrode.	Decrease amperage or select larger electrode.
Arc length too long or voltage too high.	Reduce arc length or voltage.
	Incomplete Fusion – failure of weld metal to fuse completely with base metal or a preceeding weld bead.
Possible Causes	Corrective Actions
Insufficient heat input.	Increase amperage. Select larger electrode and increase amperage.
Improper welding technique.	Place stringer bead in proper location(s) at joint during welding.
	Adjust work angle or widen groove to access bottom during welding.
	Momentarily hold arc on groove side walls when using weaving technique.
	Keep arc on leading edge of weld puddle.
Workpiece dirty.	Remove all grease, oil, moisture, rust, paint, coatings, slag, and dirt from work surface before welding.

	1
Lack of Penetration Good Penetration	Lack Of Penetration – shallow fusion between weld metal and base metal.
Possible Causes	Corrective Actions
Improper joint preparation.	Material too thick. Joint preparation and design must provide access to bottom of groove.
Improper weld technique.	Keep arc on leading edge of weld puddle.
Insufficient heat input.	Increase amperage. Select larger electrode and increase amperage.
	Reduce travel speed.
Excessive Penetration Good Penetration	Excessive Penetration – weld metal melting through base metal and hanging underneath weld.
Possible Causes	Corrective Actions
Excessive heat input.	Select lower amperage. Use smaller electrode.
	Increase and/or maintain steady travel speed.
	Burn-Through – weld metal melting completely through base metal resulting in holes where no metal remains.
Possible Causes	Corrective Actions
Excessive heat input.	Select lower amperage. Use smaller electrode.
	Increase and/or maintain steady travel speed.
	Waviness Of Bead – weld metal that is not parallel and does not cover joint formed by base metal.
Possible Causes	Corrective Actions
Unsteady hand.	Use two hands. Practice technique.
Base metal moves in the direction of the weld bead.	Distortion – contraction of weld metal during welding that forces base metal to move.
Possible Causes	Corrective Actions
Excessive heat input.	Use restraint (clamp) to hold base metal in position.
	Make tack welds along joint before starting welding operation.
	Select lower amperage for electrode.
	Increase travel speed.

SECTION 10 – SELECTING AND PREPARING A TUNGSTEN FOR DC OR AC WELDING WITH INVERTER MACHINES

gtaw_Inverter_2011-06



Whenever possible and practical, use DC weld output instead of AC weld output.

10-1. Selecting Tungsten Electrode (Wear Clean Gloves To Prevent Contamination Of Tungsten)


IF Not all tungsten electrode manufacturers use the same colors to identify tungsten type. Contact the tungsten electrode manufacturer or reference the product packaging to identify the tungsten you are using.

	Amperage Range - Gas Type♦ - Polarity					
Electrode Diameter	(DCEN) – Argon Direct Current Electrode Negative (For Use With Mild Or Stainless Steel)	AC – Argon Balance Control @ 65% Electrode Negati (For Use With Aluminum)				
	2% Ceria, 1.5% Lanthanum, Or 2% Thorium Alloy Tungstens					
.010 in. (1 mm)	Up to 25	Up to 20				
.020 in. (1 mm)	15-40	15-35				
.040 in. (1 mm)	25-85	20-80				
1/16 in. (1.6 mm)	50-160	50-150				
3/32 in. (2.4 mm)	130-250	135-235				
1/8 in. (3.2 mm)	250-400	225-360				
5/32 in. (4.0 mm)	400-500	300-450				
3/16 in (4.8 mm)	500-750	400-500				
1/4 in. (6.4 mm)	750-1000	600-800				

♦ Typical argon shielding gas flow rates are 11 to 35 CFH (cubic feet per hour).


Figures listed are a guide and are a composite of recommendations from American Welding Society (AWS) and electrode manufacturers.

10-2. Preparing Tungsten Electrode For DC Electrode Negative (DCEN) Welding Or AC Welding With Inverter Machines



SECTION 11 - GUIDELINES FOR TIG WELDING (GTAW)

11-1. Positioning The Torch



Grinding the tungsten electrode produces dust and flying sparks which can cause injury and start fires. Use local exhaust (forced ventilation) at the grinder or wear an approved respirator. Read MSDS for safety information. Consider using cerium or lanthanum based tungsten instead of thoriated. Thorium dust contains low-level radioactive material. Properly dispose of grinder dust in an environmentally safe way. Wear proper face, hand, and body protection. Keep flammables away.

Workpiece

Make sure workpiece is clean before welding.

- 2 Work Clamp
- Place as close to the weld as possible.
- 3 Torch
- 4 Filler Rod (If Applicable)
- 5 Gas Cup
- 6 Tungsten Electrode

Select and prepare tungsten according to Section 10.

Guidelines:

The inside diameter of the gas cup should be at least three times the tungsten diameter to provide adequate shielding gas coverage. (For example, if tungsten is 1/16 in. diameter, gas cup should be a minimum of 3/16 in. diameter.


Tungsten extension is the distance the tungsten extends out gas cup of torch.

The tungsten extension should be no greater than the inside diameter of the gas cup.


Arc length is the distance from the tungsten to the workpiece.

Ref. ST-161 892

11-2. Torch Movement During Welding



11-3. Positioning Torch Tungsten For Various Weld Joints







Figure 12-1. Main Assembly

Figure 12-1. Main Assembly

1	. Label, General Precautionary 1
2 156034005	. Slide Clip 1
3 156034007	. Hinge, Plastic, 40x40 2
4 +156007045	. Panel, LH 1
5 +156015030	. Threaded Ring, Spool Holder, 5kg Spool 1
6 056020078	. Handwheel Reel, w/Ring M8x20 1
7 156032137	. Spring 17x2, 6x4sp.L=19 1
8 156009146	. Clamp, Holder 17x41 – 4mm Thick 1
9 656009005	. Disk Clutch, 20x42 For Holder 5kg 1
10 656102008	. Spool Holder C/W Ring 5kg Spool 1
11 556009032	. Brass Washer, 8,5x51,5– 0,7mm Thick 1
12 156012153	. Spool Holder Shaft D.50 5kg D.16 L=58 1
13 155436	. Label, Ground 1
14 176106	. Label, Moving Parts 1
15 +156122095	. Plate, Baffle 1
16 056020080	. Knob, BBT/Slope Control 2
17 956172104	. Label, Warning Changing Polarity BBT/Slope Control 1
18 057094073	. Kit, Gas/No Gas Change Board 1
19 056020079	. Lobes D.30 Handwheel 2
20	. Box Protection, PCB 1
21	. Label, Warning Electric Shock 1
22 056126085	. Motor C/W Pinion 1
23 057021028	. Wire Drive System, C/W 0.8–1.0 Rolls, 2 Rolls 1
24 556090048	. Wire Guide, 2 X 5, L.71, Outlet 1
25 057052052	. Connector, Mini–Euro, Quick Female, L.17 1
26	. Nameplate, MPi 180 1
27 156118081	. Bezel, Front 1
28 193919	. Knob, Pointer 1.250 Dia X .250 Ld 2
29 193920	. Knob, Pointer .840 Dia X .250 Ld 1
30	. Nameplate, MPi 180 Upper 1
31 PC3 057084186	. Circuit Card, Meter 1
	. Circuit Card, BBT/Slope Control 1
	. Circuit Card, Power Interconnecting 1
34 PC1 057084188	. Circuit Card, Inverter Control 1
35 GSV . 056061071	. Valve, Gas 1
36 156005146	. Corner Seal, Plastic 2
37 +156118086	. Panel, Rear 1
38	. Nameplate, Rear 1
39 656089046	. Strain Relief, M 25x1.5, Primary Cord 1
40	. Primary Cable, 3 Core 2,5 Mq 1
41	. Nut, Gas Valve 1
42 S1 124511	. Switch, 40A 600VAC 1
43 156008044	. Spacer, Fan
44 FM1 057035022	. Fan, 120x120 24VDC C/W Wire Harness 1
45 956172110	. Rating Plate, MPi 180 1
46 156006080	. Base
47 656110015	. Foot, Rubber Mount, D.45 H=25 4
48 156118093	. Panel, Front
49	. Nameplate, MPi 180 Lower 1
50 056076270	. Dinse, Socket, Female, 25MMQ 2
51 208015	. Handle 1
52 +156122092	. Panel RH 1
53 207291	. Label, Primary Power Connections 1
54 056092098	. Fuse holder
55 F1 056092101	. Fuse, 5x20 T, 1A 250VAC 1

+ When ordering a component originally displaying a precautionary label, the label should also be ordered. To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.



Item Dia. Part No. Mkgs. No. Descrip	tion
---	------

Figure 12-2. Wire Drive Assembly

1 M	056126085 . Motor, Gear 1
2	556009033 . Motor, Plate 1
3	156018121 . Nut, Hex M5, Steel 4
4	656161010 . Cover, Rear, Gear Box Assembly 1
5	156033035 . Bushing, D.10x14, Brass 1
6	656003014 . Drive Shaft, Central Gear/Drive Roll 1
7	156012141 . Snap Ring, TR.PL-Al Es.12 L=52 1
8	156017161 Bearing, D. 10x26 1
9	156012142 . Pin, D.4x25 Sm.0,3x45ø C40 RETT 1
10	156003042 . Gear, Reducer, D32z30-D17z12 1
11	156012140 . Pin, D.4x35 Sm.0,3x45ø C40 RETT 2
12	156003041 . Gear, Reducer, D24z30-D14z12 1
13	156003040 . Gear, Reducer, D23z38-D12z14 1
14	156019825 . Screw, M3x14, Zinc Steel 2
15	356052008 . Housing, Adapter Gun/Feeder 1
16	156012155 Bushing, Upper Pressure Arm Pivot 1
17	156032132 . Spring, D. 15 1
18	156012145 . Pin, Drive Roll 1
19	056002016 . Upper Pressure Arm Housing, PVC 1
20	156019777 . Screw, M4x8, Pan Head 2
21	156009136 . Washer, D. 10,5x4, Brass
22	156013050 . Key, Upper Drive Roll Assembly, 3x3 L=15 1
23	156033036 Bushing, Upper Drive Roll Assembly 1
24	156003036 . Gear, Upper Drive Roll Assembly, D.17x32.5 1
25	156053112 Drive Roll, Upper Pressure Arm Housing, D. 17x30 1
26	156019805 Bolt, M5x25, Through Housing 3
27	756009061 . Washer, Insulator Drive Assembly Through Bolt
	156023165 . C Clip, Gear/Shaft, D.10 1
29	156013051 . Key, Lower Drive Roll Assembly, D. 3x3 L=20 1
30	156003037 . Gear, Lower Drive Roll Assembly, D.10x32,5, Drive Roll 1
31	156053051 . Wire Drive Roll, D.30, See Fig. 4-7 Refer To Table 12-1 1
32	656021268 . O-Ring, D. 7,2x1,78
33	656002022 . Thumb Screw, Drive Roll Locator, D. M4x8
34	156090022 . Wire Inlet Guide, See Fig. 4-7 Refer To Table 12-1
35	156019779 . Screw, M4x4, Wire Inlet 1
36	156012143 . Pin, D.3x13 L. 5mm, Knurled 1
37	656064003 . Tension Arm, Pinned
38	156032133 . Sleeve, D. 7x7, Spring Housing
39	156032134 . Spring, 10x1.3 L.30, Wire Tensioning
40	
41	656033009 Nut, Locating, Tension Knob 1

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

Table 12-1. Drive Roll And Wire Guide Kits

IF Base selection of drive rolls upon the following recommended usages:

- 1. V-Grooved rolls for hard wire.
- 2. U-Grooved rolls for soft and soft shelled cored wires.
- 3. V-Knurled rolls for hard shelled cored wires.
- 4. Drive roll types may be mixed to suit particular requirements (example: V-Knurled roll in combination with U-Grooved).

Wire Diameter			Drive Roll		Wire Guide	
Metric	Fraction	Decimal	Part No.	Туре	Inlet	
0.6/0.8 mm*	0.023/0.030 in.	0.023/0.030 in.	156053051	V		
0.8/1.0 mm*	0.030/0.035 in.	0.030/0.035 in.	156053109	V		
0.8/1.0 mm*	0.030/0.035 in.	0.030/0.035 in.	156053121	U	156090022	
0.8/1.0 mm**	0.030/0.045 in.	0.030/0.035 in.	156053053	U		
1.0/1.2 mm*	0.035/0.045 in.	0.035/0.045 in.	156053110	V-K		


Notes




Work like a Pro!

Pros weld and cut safely. Read the safety rules at the beginning of this manual.

Notes



Notes





Effective January 1, 2013 (Equipment with a serial number preface of MD or newer)

This limited warranty supersedes all previous Miller warranties and is exclusive with no other guarantees or warranties expressed or implied.

LIMITED WARRANTY – Subject to the terms and conditions below, ITW Welding Products Italy warrants to its original retail purchaser that new Miller equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped by Miller. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

Within the warranty periods listed below, Miller will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Miller must be notified in writing within thirty (30) days of such defect or failure, at which time Miller will provide instructions on the warranty claim procedures to be followed.

Miller shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the date the equipment was delivered to the original retail purchaser or one year after the equipment is shipped to a European distributor or eighteen months after the equipment is shipped to an International distributor.

- 1. 5 Years Parts 3 Years Labor
 - Original main power rectifiers only to include SCRs, diodes, and discrete rectifier modules with exclusion of STR, Si, STi, STH and MPi series.
- 2. 3 Years Parts and Labor
 - * Engine Driven Welding Generators (NOTE: Engines are warranted separately by the engine manufacturer.)
 - Inverter Power Sources (Unless Otherwise Stated)
 - * Process Controllers
 - Semi-Automatic and Automatic Wire Feeders
 - * Transformer/Rectifier Power Sources
 - * Water Coolant System (Integrated)
- 3. 2 Years Parts
 - * Auto-Darkening Helmet Lenses (No Labor)
 - * Migmatic 175
 - * HF Units
 - * Water Coolant Systems (EU Models, Non-Integrated)
- 4. 1 Year Parts and Labor Unless Specified
 - * Automatic Motion Devices
 - * Field Options
 - (NOTE: Field options are covered under True Blue® for the remaining warranty period of the product they are installed in, or for a minimum of one year whichever is greater.)
 - * Induction Heating Power Sources, Coolers, and Electronic Controls/Recorders
 - * Motor Driven Guns (w/exception of Spoolmate Spoolguns)
 - * Positioners and Controllers
 - * Powered Air Purifying Respirator (PAPR) Blower Unit (No Labor)
 - * Racks
 - * Running Gear and Trailers
 - * Subarc Wire Drive Assemblies
 - * Water Coolant Systems (USA Models, Non-Integrated)
 - * Work Stations/Weld Tables (No Labor)
- 5. 6 Months Parts
 - * Batteries



- 6. 90 Days Parts
 - * Accessory (Kits)
 - Canvas Covers
 - * Induction Heating Coils and Blankets
 - * MIG Guns
 - * Remote Controls
 - * Replacement Parts (No Labor)
 - * Spoolmate Spoolguns
 - * Cables and Non-Electronic Controls

Miller's True Blue® Limited Warranty shall not apply to:

- 1. Consumable components; such as contact tips, cutting nozzles, contactors, brushes, switches, slip rings, relays or parts that fail due to normal wear.
- 2. Items furnished by Miller, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
- Equipment that has been modified by any party other than Miller, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

MILLER PRODUCTS ARE INTENDED FOR PURCHASE AND USE BY COMMERCIAL/INDUSTRIAL USERS AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at Miller's option: (1) repair; or (2) replacement; or, where authorized in writing by Miller in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized Miller service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. Miller's option of repair or replacement will be F.O.B., Factory at ITW Welding Products Group Europe or F.O.B. at a Miller authorized service facility as determined by Miller. Therefore no compensation or reimbursement for transportation costs of any kind will be allowed.

TO THE EXTENT PERMITTED BY LAW, THE REMEDIES PROVIDED HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT), WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MILLER IS EXCLUDED AND DISCLAIMED BY MILLER.



Please complete and retain with your personal records.

Model Name	Serial/Style Number	
Purchase Date	(Date which equipment was delivered to original customer.)	
Distributor		
Address		
Country	Zip/Postal Code	



Contact a DISTRIBUTOR or SERVICE AGENCY near you.

Always provide Model Name and Serial/Style Number.

Contact your Distributor for:

Welding Supplies and Consumables Options and Accessories Service and Repair Replacement Parts Owner's Manuals

Contact the Delivering Carrier to:

File a claim for loss or damage during shipment.

For assistance in filing or settling claims, contact your distributor and/or equipment manufacturer's Transportation Department. ITW Welding Italy S.r.I.

Via Privata Iseo, 6/E 20098 San Giuliano Milanese, Italy Phone: 39 (0) 2982901 Fax: 39 (0) 298290-203 email: miller@itw-welding.it

